

MOUNTING PROCEDURE

KIT SAVE CARTER
KAWASAKI Z-750 '07 - '13
KAWASAKI Z-1000 '07 - '09

KN7101-07

WWW.BARRACUDAMOTO.COM

KIT

X2. PVC HEAD
X2. SAVE CARTER BASE
X1. SPACER "A"
X1. SPACER "B"
X1. BOLT 8X70
X1. BOLT 8X100
X2. WASHER DIAMETER 8



LEFT SIDE:

REMOVE THE ORIGINAL BUSH AND USE THE SAVE CARTER WITH THE LONG SPACER "A"



RIGHT SIDE:

REMOVE THE ORIGINAL BUSH AND USE THE SAVE CARTER WITH THE LONG SPACER "B"

Right Side
Bolt 80x70

"B"

"A"

Left Side
Bolt 80x100



BEFORE BEGINNING ASSEMBLY, FIND THE MOUNTING POINTS ON THE MOTORBIKE, USE THE SHIMS AND BOLTS AS DESCRIBED IN THE PICTURE IN ORDER TO GET THE RIGHT PROJECTION OF THE BUFFER FROM THE BIKE.

FIT THE HEAD PAD IN PVC ONLY AFTER YOU HAVE INSTALLED AND TIGHTENED UP ALL THE KIT.