

## ASSEMBLING INSTRUCTION

### CRASH PAD KIT

YMT9101-21

WWW.BARRACUDAMOTO.COM

### LEGEND

- |   |   |   |
|---|---|---|
| 1. CRASH PAD HEAD<br>TESTA TAMPONE<br>CABEZA CRASH PAD<br>KOPF CRASH PAD<br>TÊTE DE CRASH PAD | 3. HEX HEAD SCREW M10X140<br>VITE TESTA ESAGONALE M10X140<br>TORNILLO DE CABEZA HEXAGONAL M10X140<br>SECHSKANTSCHRAUBE M10X140<br>VIS À TÊTE HEXAGONALE M10X140 | 5. HEX HEAD SCREW M10X100<br>VITE TESTA ESAGONALE M10X100<br>TORNILLO DE CABEZA HEXAGONAL M10X100<br>SECHSKANTSCHRAUBE M10X100<br>VIS À TÊTE HEXAGONALE M10X100 |
| 2. BASE PAD<br>BASE TAMPONE<br>BASE DE TOPE<br>STURZPAD BASIS<br>BASE TAMPON                  | 4. SPACER TUBE H. 70<br>Distanziale H. 70<br>Distanciador H. 70<br>Distanzrohr H. 70<br>Espaceur H. 70  | 6. SPACER TUBE H. 35<br>Distanziale H. 35<br>Distanciador H. 35<br>Distanzrohr H. 35<br>Espaceur H. 35  |

LEFT SIDE

RIGHT SIDE

